

ホットシューアダプターF・延長コードF の使い方 HOT-SHOE ADAPTER F & 5P SYNC CORD F

使用説明書



ホットシューアダプターFと延長コードF〔5P〕は、写真のように、SFXカメラからAF400FTZやAF240FTを離して使うときに用います。

また、AF080Cリングライト用コントロールパックなどを、SFXのホットシューに取りつけるときは、このアダプターを使うとシャッターボタンやセレクターの操作がしやすくなりますのでご利用ください。

- 写真のように、SFXの内蔵ストロボとAF400FTZやAF240FTで増灯撮影ができます。
- ストロボをカメラから離して使うときは、AFスポットビームが正確に被写体にあたらないのでスポットビームの使用はできません。
- 上図×印のように、ホットシューアダプターFの上にはストロボを付けしないでください。
- 従来のアクセサリ「ホットシューグリップ」などに、組合わせて使用しないでください。信号接点が異なり、ショートすることがありますのでご注意ください。

ホットシューアダプターF

使用カメラ—ペンタックスSFX

使用ストロボ—AF400FTZ・AF240FT

AF080Cリングライトセット

大きさ・重さ—30〔幅〕×24〔高〕×28.5〔厚〕mm 25g

Connecting the SFX/SF1 camera with the AF400FTZ or AF240FT flash unit, these two accessories enable you to take flash photographs with the flash unit detached from the camera. When also fitting the Control Pack for the AF080C Ring Light, etc. on the camera's hot shoe, using this Adapter makes it easier to operate the shutter button and the select switch.

- As shown above, these accessories enable you to use the camera's built-in flash and the AF400FTZ or AF240FT simultaneously.
- When using the flash unit off the camera, the AF spotbeam is not applicable as it does not properly illuminate the subject.
- As "X"-marked above, do not use the flash by mounting it on the Adapter.
- Do not use the Adapter on the accessory such as Hot-Shoe Grip, since their signal contacts do not match and may cause short-circuit.

Hot-Shoe Adapter F

Camera to use with—Pentax SFX/SF1

Flashes to use with—AF400FTZ, AF240FT, AF080C Ring Light Set

Dimensions—30(W) x 24(H) x 28.5(D)mm

Weight—25 grams



旭光学工業株式会社

〒114 東京都板橋区前野町2丁目36番9号 ☎03(960)5151(代)

旭光学商事株式会社

〒100 東京都千代田区永田町1丁目11番1号 ☎03(580)2051(代)